

photoweights®

Glass Paperweights Designed to Display Photos, Artwork, Crafts, and Small Curiosities

ASSEMBLY INSTRUCTIONS




Before you begin your project, it's important to clean your paperweights with streak-free glass cleaner to remove any fingerprints, dust, or smudges. This step will also help ensure the adhesive bottom pad adheres properly to the surface of the glass.



1. Each paperweight kit includes a mounting board and a bottom pad, as shown.
2. Remove the protective film to expose the adhesive on the mounting board.
3. Place the adhesive side of the board onto the back of the image being displayed in the paperweight.



4. Using a pair of scissors, trim any material that extends beyond the edge of the mounting board.
5. Place the mounting board (image side down) within the recessed area on the bottom of the paperweight.
6. Remove the protective film to expose the adhesive on the bottom pad.



7. Carefully center the pad over the base of the paperweight and apply.