


photoweights®

Glass Paperweights Designed to Display Photos, Artwork, Crafts, and Small Curiosities

ASSEMBLY INSTRUCTIONS - DOMES



Before you begin your project, it's important to clean your paperweights with streak-free glass cleaner to remove any fingerprints, dust, or smudges. This step will also help ensure the adhesive bottom pad adheres properly to the surface of the glass.



1. Your glass paperweight includes a mounting board and a bottom pad.
2. Remove the protective film to expose the adhesive on the mounting board.
3. Place the adhesive side of the board onto the back of the image being displayed in the paperweight. If you are displaying a dimensional item, such as a memento or artwork, use fabric or paper to act as a background (as shown).



4. Using a pair of scissors, trim any material that extends beyond the edge of the mounting board.
5. (Optional) Dimensional items should be attached directly to the prepared mounting board. Allow any glue to dry completely.
6. Remove the protective film to expose the adhesive on the bottom pad.



7. Apply the finished mounting board to the center of the adhesive side of the bottom pad.
8. Center the bottom pad over the base of the paperweight (upside down) and slowly lower it onto the glass to secure.